


# Scene Driveguard 800Plus Manual

โครงสร้างสินค้า



1	เลนส์	5	ช่องรีเซ็ต	9	จอแสดงผล	13	OK
2	ช่องต่อกล้อง หลัง	6	ช่องไมโครโฟน	10	ปุ่มขึ้น/ซ้าย	14	ปุ่มโหมด
3	ช่องต่อขายึด	7	ไฟแสดงสถานะ	11	ปุ่มเมนู	15	ปุ่มล๊อค
4	ช่องต่อไฟเข้า	8	ช่องใส่ SD Card	12	ปุ่มลง/ขวา	16	ปุ่มเปิด/ปิด

ปุ่มต่างๆ

## “ปุ่มเปิด/ปิด”

กดค้าง 2 วินาทีเพื่อ เปิด/ปิดเครื่อง

กดเพื่อเปิด/ปิดหน้าจอ

หมายเหตุ: ระหว่างที่กล้องทำงาน กด ครั้งเพื่อปิดจอ และกดซ้ำอีกครั้งเพื่อเปิดจอ

## “ปุ่มลือค”

ลือค ไฟล์ลูกเงิน

หมายเหตุ: ขณะที่กล้องกำลังบันทึกวิดีโอ หากต้องการบันทึกวิดีโอเป็นกรณีพิเศษให้กดปุ่มลือคไฟล์ เพื่อที่กล้องจะทำการรีแคฟไฟล์นี้ ไปอยู่ในโฟลเดอร์อื่นเพื่อจะได้ไม่ปนกับโฟลเดอร์ปกติ

## “ปุ่มโหมด”

กดเพื่อเปลี่ยน โหมด จาก วิดีโอ → ถ่ายภาพ → ดูภาพย้อนหลัง

## “ปุ่มOK”

ฟังก์ชัน 1: กดบันทึก/กดหยุดวิดีโอ.

ฟังก์ชัน 2: กดถ่ายภาพในโหมด การถ่ายภาพ

ฟังก์ชัน 3: ในโหมดดูภาพย้อนหลัง กดเพื่อเล่นไฟล์.

ฟังก์ชัน 4: Used as the button “OK”.

Under the “standby” mode, “shooting” and “replay”, long press [Menu], then shortly press [UP / Down] to browse the files, shortly press [OK] to confirm the file.

## “ปุ่มลง”

ฟังก์ชัน: กดเลื่อนลง


“ปุ่มลง”

ฟังก์ชัน: กดเลื่อนขึ้น

ฟังก์ชัน 2: เปลี่ยนหน้าจอกล้องจากกล้องหน้าไปกล้องหลัง

“ปุ่มเมนู”

ฟังก์ชัน: เมนู กดเพื่อเข้าหน้าเมนูและกดอีกครั้งเพื่อออกจากหน้าเมนู



## เตรียมตัวสำหรับการใช้ครั้งแรก

### การติดตั้ง

1. ตำแหน่งที่ติดตั้งกล้องทั้งหน้าและหลังไม่ควรที่จะบดบังวิสัยทัศน์ในการขับขี่
2. สำหรับรถบางคัน จะมีการจ่ายไฟผ่านกล่องจุดบุหรี่หลังจากดับเครื่องยนต์แล้ว ดังนั้นควรที่จะดึงคาร์ชารจ์เจอร์ออกเพื่อป้องกันการเกิดอุบัติเหตุ

### ● เปิด/ปิด

#### 1. เปิด:

- 1) กล้องจะเปิดให้อัตโนมัติหลังจากที่รถสตาร์ทเครื่องยนต์;
- 2) ทำการกดปุ่มเปิด ค้างไว้ 2 วินาทีเพื่อทำการเปิดกล้อง

#### 2. ปิด:

- 1) กล้องจะปิดให้อัตโนมัติหลังจากที่รถดับเครื่องยนต์;
- 2) ทำการกดปุ่มเปิด/ปิด ค้างไว้ 2 วินาทีเพื่อทำการปิดกล้อง

### ● การเลือก Micro SD Card

1. Micro SD Card ที่ใช้สำหรับกล้องรุ่นนี้ให้ใช้ที่เป็น Class10 U3 สามารถรองรับได้สูงสุด 128GB
2. ถ้าต้องการถอดการ์ดออกให้กดที่ตัวการ์ด กล้องจะทำการดันการ์ดออกมา.
3. การใช้การ์ดครั้งแรก ควรที่จะต้องฟอร์แมตการ์ดจากกล่องเสมอ และหากใช้การ์ดที่มีความจุขนาด 64GB ขึ้นไป จำเป็นที่จะต้องฟอร์แมตการ์ดผ่านตัวกล้องก่อนใช้งาน

# คำสั่งในเมนู

ช่วงเวลาวิดีโอ: 1 นาที, 3 นาที, 5 นาที

รอบบันทึกในแต่ละช่วงวิดีโอ

เสียงในวิดีโอ: เปิด/ปิด

G-Sensor: ปิด/ต่ำ/กลาง/สูง

เมื่อถูกแรงกระแทก กล้องจะทำการย้ายโฟกัสไปอยู่ที่โฟลเดอร์

บันทึกป้ายทะเบียน: ตั้งค่าเลขป้ายทะเบียนเพื่อบันทึกในหลายน้ำวิดีโอ

พักหน้าจอ: ปิด/นาที/3นาที กล้องจะทำการดับหน้าจอหลังจากครบเวลาที่ตั้งไว้

Video coding: H265 and H264.

Light source frequency: 60HZ and 50 HZ.

ปุ่มเสียง: เปิด/ปิด

เสียงลำโพง: เงียบ/ต่ำ/กลาง/สูง

ภาษา: มีภาษาไทย

ตั้งแต่วันที่: 2031/01/01/24/24

ฟอร์แมตการ์ด: มี

คืนกลับค่าโรงงาน: มี

About: software version.


## Technical specification

LCD screen	3.0 inch IPS full-view display screen
Camera Lens	High resolution camera with a 6G Lens
Language	<b>English, Simplified Chinese, Traditional Chinese, Japanese, русский, Deutsch, Français, Español and Italiano, Thai</b>
Video	3840*2160 /1920*1080
Video format	MP4
Photo format	JPEG
Microphone /	Built-in
Light source	50Hz/60Hz
USB interface	USB2.0
Power interface	5.0V 2A
Battery	Built-in super capacitor

หมายเหตุ: อาจมีการปรับเปลี่ยนสเปคโดยไม่ได้แจ้งให้ทราบล่วงหน้า โปรดสังเกตที่สินค้าจริง

# Scene Driveguard 800Plus Manual

## Product structure



1	Camera	5	Reset hole	9	Display screen	13	OK
2	Rearcam interface	6	Microphone hole	10	Up / Left	14	Mode
3	Holder surface	7	Indicating light	11	Menu	15	Lock
4	USB Interface	8	TF card slot	12	Down / Right	16	Power



## **Buttons**

### **Button “Power”**

Function 1: Long press 2 seconds turn on/off function

Function 2: Turn off the display screen function

Note: When car black box is turn on, press the [Power] button, the unit will turn off the display, and tap again to turn on the display.

### **Button “Lock”**

Function: emergent lock

Note: under the “video recording” mode, if the current video needs to be protected but not covered by later ones, shortly press [emergent lock] to trigger the function of emergency lock; then the current video will be saved as a special video and it will not be covered by others.

### **Button “Mode”**

In “standby” mode, shortly press [mode] button to switch between different modes (recording/photographing/playback).

### **Button “OK”**

Function 1: Start up / shut down the function “video”.

Under the “video” mode, shortly press “OK” to start recording, shortly press [OK] again to stop.

Function 2: Shooting

Under the “shooting” mode, shortly press [OK] for one time, then one photo can be taken.

Function 3: play the files

In the file browsing mode, short press [Enter] to play the video.

Function 4: Used as the button “OK”.

Under the “standby” mode, “shooting” and “replay”, long press [Menu], then shortly press [UP / Down] to browse the files, shortly press [OK] to confirm the file.

### **Button ‘Down’**

Function: Page down

Under the mode “menu” and “replay”, page down.

### **Button “Up”**

Function 1: Page up.

Under the mode “menu” and “replay”, page up.

Function 2: Switch over cameras.


After the rear camera is accessed, double cameras will be displayed. Under the mode “Video”, shortly press [Up] to switch over among the front camera, PIP (picture in picture) and rear camera; under the mode “shooting”, the rear camera and front camera can be switched over.

### **Button “Menu”**

Function: Menu.

Under “standby”, shortly press [Menu] to access to function setting. After the setting, shortly press [Menu] to log out the setting. (Setting is the same when under the mode “video”,

“shooting” and “replay”).



## **Preparation for First Use**

### **Installation**

3. According to the interior environment, tightly fix the vehicle-mounted power cord; in order not to adversely affect your eyesight, the car black box shall be installed in front of the rear view mirror in the car. In this way, you can get a better and wider view.

4. Do not install the car black box at a place where it will adversely affect the driver's attention or where it will block the driver's view.

5. For some cars, the power will be supplied to the car black box after the car is shut

down; if so, it is mandatory to pull out the vehicle-mounted power, otherwise, accident will be resulted in.

- **On/Off**

- 1. On:**

- 1) The car black box will turn on automatically when the car is started up;
- 2) The car black box can be started manually by pressing the On/Off button for 2 seconds.

- 2. Off:**

- 1) The car black box will turn off automatically when the car is shut down;
- 2) The car black box can be stopped manually by pressing the On/Off button for 2 seconds.

- **Selection of Memory Card**

1. Memory card (micro SD card or micro SDHC card) shall be additionally bought by the user, which is not included in the car black box. Please use the high-speed TF card (U3 required), whose capacity shall be no less than 8GB, maximal of TF card is 128GB.

2. If you need to get out the memory card; then slightly press the bottom of the memory card, by which the card will be sprang up; get out the card with your fingers gently.

3. Before the first use, TF card shall be formatted.

## **Menu instructions**

**Video time: 1min., 3 min. and 5 min.**

Note: Cycling time of each video.

**Video sound: on and off.**

Note: When recording the video, the sound will be recorded synchronously; when the sound is off, the recording video will be mute.

**Collision sensitivity: off, low, medium and high.**

Note: When making the video, if there is a crash or impact, the video will be locked.

**License plate number: Set the license plate number.**

Note: Set a license plate number used in Mainland China.

**Screen saver: Off, 1min. and 3 min.**

Note: When the recorder is not operated for X minutes, the camera will turn off the LCD screen display, and press any button, the screen will turn on.

**Video coding: H265 and H264.**

Note: Video code format can be selected, H265 is the default.

**Light source frequency: 60HZ and 50 HZ.**

**USB mode: Use USB cable to connect with a computer.**

**Button-pressing sound: On and off.**

**Speaker volume: silence, low, medium and high;**

**On / off sound: On and off;**

**Language:**

**English, Simplified Chinese, Traditional Chinese, Japanese, русский, Deutsch, Français, Español and Italiano.**

**Time setting: 2031/01/01/24/24**

**Format memory card: Yes and no.**

Note: Confirm to format the SD card.

**Factory data reset: Yes and no.**

Note: After resetting the system, camera function will be recovered as the defaulted.

**About: software version.**

## **Technical specification**

LCD screen	3.0 inch IPS full-view display screen
Camera Lens	High resolution camera with a 6G Lens

Language	<b>English, Simplified Chinese, Traditional Chinese, Japanese, русский, Deutsch, Français, Español and Italiano. Thai</b>
Video	3840*2160 /1920*1080
Video format	MP4
Photo format	JPEG
Microphone / Speaker /	Built-in
Light source	50Hz/60Hz
USB interface	USB2.0
Power interface	5.0V 2A
Battery	Built-in super capacitor

**Note: This product retains design and specifications without prior notice. If there are differences, please refer to the actual unit.**